PANCHO VILLA'S BISLEY COLT

"Human behaviour flows from three main sources: desire, emotion and knowledge."

Plato

Caesar traversed the Rubicon, Alexander entered Asia Minor and Pancho Villa crossed the Texas-Mexico border, taking with him the time-honoured code of the verdaderos hombres or 'true men'.

He was a man born at a time of great technological innovation: the first phone call was made when he was two, and the Kodak camera was invented in his eleventh year.

His revolver became a legend after him.

It conferred the power to stop time:
to eliminate the potentially fatal vulnerability
of the reloading process.

This is the story of a great man and his unrivalled companion.


Every revolution is founded on exclusivity, secrecy and complicity.

The higher the stakes, the harder it is to become part of the inner circle. Writer and journalist John Reed described Villa's El Paso as the 'Supreme Lodge of the Ancient Order'.

Only three years separate the founding of L'Epée and Samuel Colt's patent for the mechanically indexing cylinder that would make the revolver possible.

Nearly two centuries later, The Unnamed Society has commissioned the masters of the art of time to create Pancho Villa's Bisley Colt for the visionary collectors in its select circle.

THE MAKING OF





L'Epée was founded in 1839.

The year when John Davidson Rockerfeller Sr. was born and Louis Daguerre took the first photograph of the moon.

Today, the company is based in Delémont in the Swiss Jura Mountains, where it crafts its growing collection of uniquely exclusive horological masterpieces.



CERTIFICATE

CERTIFICATE OF ORIGIN

We hereby certify that this ArtPiece has been created, crafted and tested by L'Epee Masters in Switzerland.

Ref.

14 6003 1 1104

Movement

Jewels

17

Material

Palladium)

Signature for final control



CERTIFICATE OF PURCHASE

Model

TRAHAT 41

Reference Number

Owner's Name

Official stamp





TUS Founder

NEW OWNER

Owner's Name	
Date of Purchase	
Owner's Name	
Date of Purchase	
Date of Furchase	

CERTIFICATE OF GUARANTEE

As for all Horological pieces of art, it is recommended that your clock is serviced periodically. A mechanical masterpiece requires fine oils for the lubrication of the movement. These oils deteriorate over the years. We therefore advise having the movement serviced every 3 years.

Be aware that the optimal period between servicing times can vary depending on the surrounding environmental conditions.

Warranty: 5 years


Date of purchase

Contact: +41 32 557 57 97 info@theunnamnedsociety.com

MAINTENANCE

USER INSTRUCTIONS

CARE AND MAINTENANCE



Zones in brown are very fragile; ensure all contact is avoided (finger, tissue or liquid spray, for example).

The movement of Pancho Villa's Bisley Colt is fragile. Some gears are accessible. Please be careful when handling the clock, and do not touch these parts (highlighted).

Pancho Villa's Bisley Colt is weighs 1.9 kg. It is recommended that Pancho Villa's Bisley Colt is handled by the grip, shown here in blue.

Our clocks are developed to ensure optimal accuracy and reliability.

It is an accepted principle that a fine mechanical clock will have a few seconds' variation per day and our clocks are set so as to not lose time. However if you should notice a bigger variation, please contact an authorized dealer who will advise you, or a L'Epee 1839 technical support center which will proceed with the necessary adjustment.


As for all Horological works of art, it is recommended that your clock is serviced periodically. A mechanical masterpiece requires fine oils for the lubrication of the movement. These oils deteriorate over the years. We therefore advise having the movement serviced every 3 to 5 years. Be aware that the optimal period between servicing times can vary depending on the surrounding environmental conditions.

The clock should never be in contact with any liquids - even in vaporized form. If it occurs, the clock should be serviced immediately. Use only a clean, soft and dry cloth to clean the clock. Dust and particles contained in the cloth could scratch parts.

Do not use any kind of cleaning products to wipe the clock. It is recommended to keep the clock away from any source of heat or vibrations. To preserve the longevity and functionality of Pancho Villa's Bisley Colt, do not permanently place the clock in direct sunlight or in a humid or dusty location.

Simply coming into contact with certain parts can cause the clock to lose time. A service will then be required to resolve this issue. Fingerprints will also damage the finishings.

NOTES



USER INSTRUCTIONS


KINETIC SCULPTURE

KINETIC SCULPTURE

Pancho Villa's Bisley Colt is delivered with its own stand.




Position 1



Position 2


The hammer and trigger are operational (but do not affect timekeeping).




Pancho Villa's Bisley Colt can be displayed in two different positions.

Either the barrel or the grip can be clipped into the stand as below.

Position 01.




Position 02.





Every element of the final piece is made and assembled by hand and can be personalised accordingly at the owners request.



USER INSTRUCTIONS


HOROLOGICAL FUNCTIONS

WINDING THE MOVEMENT

The movement should be fully wound every seven days.
Use the dedicated winding key to wind the movement.



Place it inside the cannon (see below). You should feel a small amount of resistance while turning the key; this signals that the key is in the right position to start winding.




Ensure the spring is fully wound. At the end of the winding procedure, you will feel a significant increase in the force required; do not continue to wind as this signals that the movement is fully wound.

SETTING THE TIME

The time is set directly via the minute dome, shown here in brown. Turn clockwise. The dome should rotate freely, with no points of resistance.

Never apply too much force on the minute dome. Take care not to touch the hour crown.

We recommend that gloves are worn when handling the clock and adjusting the time to prevent any damage (such as fingerprints).




HOURS AND MINUTE DISPLAY

Hours and minutes are displayed on the hour crown and minute dome, as shown below.

Example:

8h25m



2h50m

